

microHDMI

SD card

GND	REF1	GND	REF1	GND	REF1	GND	REF1	GND	REF1	GND	REF1
284	250	218	191	85	23	146	215	382	30	366	267
252	280	188	159	17	117	240	247	94	60	303	265
314	248	220	189	53	115	208	245	62	92	335	297
282	316	158	221	51	21	144	145	380	90	333	334
344	317	190	219	81	83	176	177	378	95	365	302
312	346	121	127	87	19	246	213	26	28	363	364
351	347	153	125	49	113	214	181	58	383	367	332
319	251	223	123	82	119	244	183	56	376	271	362
255	249	222	217	50	55	212	151	377	88	269	301
287	281	184	185	52	54	148	179	24	25	328	299
349	253	216	187	20	86	182	211	29	59	360	331
254	285	154	155	114	118	150	241	27	379	330	298
286	283	186	157	16	48	180	209	31	381	300	268
348	315	124	152	22	80	242	147	61	89	264	270
350	313	156	120	116	112	210	243	63	57	296	329
318	345	126	122	84	18	178	149	93	91	266	361
REF2	GND	REF2	GND	REF2	GND	REF2	GND	REF2	GND	REF2	GND

GND	REF1	GND	REF1	GND	REF1	GND	REF1	GND	REF1	GND	REF1
306	368	192	96	7	323	170	172	261	293	13	15
274	336	130	132	321	327	202	140	291	295	11	47
277	337	160	100	33	359	232	142	225	231	43	45
339	276	98	129	353	39	136	233	257	227	46	77
371	370	128	131	3	322	200	201	65	263	14	75
341	338	194	163	35	1	206	171	229	66	76	107
309	369	162	195	355	325	174	143	64	288	44	105
311	307	97	198	5	357	236	173	224	258	106	41
279	275	161	199	354	37	204	137	68	259	74	73
340	308	99	101	358	326	234	141	228	69	104	9
278	305	193	133	34	6	238	203	292	67	40	8
310	273	102	103	2	36	175	237	230	290	72	111
272	373	164	135	32	38	207	235	262	260	10	78
304	375	196	167	352	324	205	139	226	294	42	108
372	343	134	165	0	356	239	168	256	289	12	109
342	374	166	197	320	4	169	138	70	71	110	79
REF2	GND	REF2	GND	REF2	GND	REF2	GND	REF2	GND	REF2	GND

view from the top of the Pixie

Captive
screw