

microHDMI

Molex 2049270601

284	190	246	X	X	X	382	254	222	255	319	383	159	253
252	158	214	X	X	X	126	286	223	287	351	95	191	285
314	220	276	266	X	X	94	348	316	349	31	127	189	283
282	188	244	296	X	X	156	380	317	381	63	125	221	315
344	250	370	326	X	X	124	378	346	379	61	157	219	313
312	218	338	6	GND	X	186	28	347	29	93	155	251	345
374	280	82	36	GND	X	154	26	376	27	91	187	249	343
342	248	50	38	GND	X	216	58	377	59	123	185	281	375
22	310	176	132	GND	292	184	56	24	57	121	217	279	373
372	278	144	100	GND	322	318	88	25	89	153	215	311	23
116	340	270	68	GND	260	350	86	54	87	151	247	309	85
84	308	238	X	X	290	30	118	55	119	183	245	341	117
210	52	300	264	X	325	62	148	78	149	181	277	21	179
178	20	268	294	X	355	60	180	79	243	213	339	53	211
304	146	330	324	X	357	92	242	108	337	275	371	115	273
272	114	298	356	X	5	90	274	109	49	307	51	147	305
16	240	360	4	X	37	122	336	138	111	369	83	209	367
366	208	328	354	X	X	120	368	139	143	19	145	241	17
46	334	8	X	X	X	152	48	168	141	81	177	303	15
14	302	358	X	X	X	150	80	169	173	113	239	335	47
76	364	162	66	289	67	182	110	198	171	175	271	333	45
44	332	256	96	1	161	212	142	199	203	207	269	365	77
106	12	194	34	321	99	306	140	228	201	205	301	363	75
74	362	226	64	33	193	18	172	229	233	237	299	13	107
136	42	224	2	353	131	112	170	258	231	235	331	11	105
104	10	192	32	65	225	206	202	259	263	267	329	43	137
166	72	130	352	3	163	174	200	7	293	265	361	41	135
134	40	160	0	97	257	236	232	69	323	297	359	73	167
196	102	98	320	35	195	204	230	101	261	295	9	71	165
164	70	128	288	129	227	234	262	133	291	327	39	103	197

SD card

Captive
screw

view from the top of the Pixie